



Golden Rodtronics
13401 West 43rd Drive #17
Golden Colorado
80403
Phone 303-423-8597
Fax 303-420-4575



Power Cowl Vent

1. Remove Existing cowl vent handle. In some applications the stock arm/bracket may be attached directly to the drive wheel.
2. Attach the stock arm to the hole on the drive wheel using the S.S. Button Head and lock nut provided. Leave the locknut slightly loose in order to rotate without binding.
3. With the vent closed and the drive wheel at its farthest travel position, place the mounting bracket against the firewall, and drill the ¼" mounting holes (if you are installing in a "39-40" Ford simply drill out the factory rivets on the stock firewall bracket and bolt the new bracket in it's place).
4. After all the wiring is completed, test the installation. The motor should revolve 360 degrees without strain on any parts.

